



# CameraCleanse descaler AMS

Powerful phosphoric acid based descaler for camera devices of DairyProQ and Monobox systems

Reliably removes limescale deposits from camera lens and camera housings.

## Characteristics and product advantages

- **Powerful Cleaning.**  
CameraCleanse descaler AMS easily removes even persistent limescale deposits.
- **Material-friendly.**  
CameraCleanse descaler AMS ensures the proper functioning of the camera systems without attacking or damaging the external components.
- **Tested Quality.**  
The material compatibility of CameraCleanse descaler AMS with the DairyProQ and Monobox systems was extensively tested. CameraCleanse descaler AMS is - besides CameraCleanse AMS - the only cleaner released for camera devices of DairyProQ and Monobox systems.
- **Ready-to-use – immediate application.**  
CameraCleanse descaler AMS is a ready to use product, no mixing is required.
- **Economical in use.**  
The handy bottle allows a very economical dosage.



# CameraCleanse descaler AMS

Powerful phosphoric acid based descaler for camera devices of DairyProQ and Monobox systems



## Information on use



Ready-to-use solution.  
Do not dilute.

## Application



1. Remove general dirt from the camera glass. Apply the product on a clean, lint-free textile or paper cloth and press it onto the camera glass for 5 to 10 minutes. **Do not use microfibre cloths as they can scratch the lens.**
2. After that, remove the cloth and clean up any product residues, also between camera and camera housing by rinsing with clean water.
3. Finally, dry the camera with a dry, clean and lint-free textile or paper cloth.

Avoid contact with skin and eyes. Adequate ventilation must be ensured. Wear protective gloves / protective clothing / eye protection / face protection.

## Storage

Store in cool but frost-free conditions. Protect from exposure to direct sunlight. Keep away from food, drink and animal feeding stuffs. Once dispensed, this product should not be reintroduced to its original packaging. Do not mix with other cleaning agents. Keep containers tightly closed.  
Expiry Date: Provided storage precautions are adhered to, see „Best before“ date printed on the label.

## Ordering information

Part number	Product	Size/weight
7724-7080-100	CameraCleanse descaler AMS	1 kg
7724-7080-500	CameraCleanse descaler AMS	5 kg

## Product information

General formulation: Phosphoric acid  
Density: 1,0 g/cm<sup>3</sup> at 20 °C  
pH-value: 1,5 at 20 °C (undiluted)

## Special instructions

For optimal cleaning results the alternating use of CameraCleanse AMS is recommended.

**Do not use organic acids and microfibre cloths to clean the cameras.**

## Further information

Your GEA Specialist and your local dealer will be pleased to help if you have any further questions.

GEA Farm Technologies GmbH

Siemensstraße 25 - 27, D-59199 Bönen  
Phone +49 (0) 23 83 93 7-0, Fax +49 (0) 23 83 93 8-0  
www.gea.com