



CameraCleanse AMS

Powerful special cleaning agent for camera devices of DairyProQ and Monobox systems

Reliably removes dirt from camera lens and camera housings.

Characteristics and product advantages

- **Innovative.**

Camera Cleanse AMS is a powerful special cleaning agent specially developed for camera devices of DairyProQ and Monobox systems. CameraCleanse AMS is tailored to remove typical contamination in milking parlors which makes it different from standard glass or window cleaners.

- **Powerful Cleaning.**

CameraCleanse AMS is based on a complex mixture of extraordinary high-performing but still gentle anionic surfactants which – according to OECD agreed test methods – are readily biodegradable and do not have a potential for bioaccumulation in organisms. Bioalcohol and special solvents with a favourable ecotoxicological profile support its streak-free cleaning performance.

- **Material-friendly.**

CameraCleanse AMS ensures the proper functioning of the camera systems without attacking or damaging the external components.

- **Tested Quality.**

The material compatibility of CameraCleanse AMS with the DairyProQ and Monobox systems was extensively tested. CameraCleanse AMS is – besides CameraCleanse descaler AMS – the only cleaner released for camera devices of DairyProQ and Monobox systems.

- **Ready-to-use – immediate application.**

CameraCleanse AMS is a ready to use product, no mixing is required. Spray, soak and wipe off!

- **Economical in use.**

The spray and foaming function allows a very economical dosage.



CameraCleanse AMS

Powerful special cleaning agent for camera devices of DairyProQ and Monobox systems



Information on use



Ready-to-use solution.
Do not dilute.

Application



1. Spray the product directly onto the camera glass, dispense it with a clean, lint-free textile or paper cloth. **Do not use microfibre cloths as they can scratch the lens!**
2. Let it soak for a moment.
3. Then wipe it off with the dissolved dirt. If necessary, repeat the process. The camera glasses must be free of stripes and streaks.

In order to prevent spray mist, the product can be applied directly onto the cleaning cloth. Avoid contact with skin and eyes. Adequate ventilation must be ensured.

Storage

Store in cool but frost-free conditions. Protect from exposure to direct sunlight. Keep away from food, drink and animal feeding stuffs. Once dispensed, this product should not be reintroduced to its original packaging. Do not mix with other cleaning agents. Keep containers tightly closed.
Expiry Date: Provided storage precautions are adhered to, see „Best before“ date printed on the label.

Product information

General formulation: < 5 % anionic surfactants
Other ingredients: Solvents
Density: 0,98 g/cm³ at 20 °C
pH-value: 8,5 at 20 °C (undiluted)

Special instructions

For optimal cleaning results the alternating use of CameraCleanse descaler AMS is recommended.

Do not use organic acids and microfibre cloths to clean the cameras.

Further information

Your GEA Specialist and your local dealer will be pleased to help if you have any further questions.

Ordering information

Part number	Product	Size/weight
7724-7070-100	CameraCleanse AMS	1 kg
7724-7070-500	CameraCleanse AMS	5 kg

GEA Farm Technologies GmbH

Siemensstraße 25 - 27, D-59199 Bönen
Phone +49 (0) 23 83 93 7-0, Fax +49 (0) 23 83 93 8-0
www.gea.com